



“PORTABLE LED LAMP”

WARNINGS



Before to use the tool, please read carefully the instruction contained in this manual. Improper or unsafe use of this tool can result in death or serious bodily injury. This manual of instructions constitutes an integral part of product and it has to be edited by the end user for every possible future consultation. It contains important informations about the safety use of the product.



Use destination.

This tool and its accessories, must only be used for the purpose for which they have been conceived. A different use from that one suitable could cause damages to people, animals or things and it's considered improper and unreasonable action. The producer can't be considered responsible for possible damages caused by improper, wrong and unreasonable uses, as, for example, the un-observance of the safety instruction, the use of no original accessories and operation not authorized on the product.

Precautions for use

The information in this section will help you to comply with the warranty requirements and keep the lamp in good working order.

- Turn off the lamp when it is not in use.
- Never leave the lamp with the battery completely empty.
- Fully recharge the battery if the lamp is not to be used for a long time (one month or more).
- Charge the lamp battery for 10 hours before first use.
- Before cleaning the lamp, always disconnect the charging cable.
- Clean preferably with a dry or slightly damp cloth. Do not use solvents, alcohol, corrosive chemicals or aggressive detergents.
- To use, charge and store the lamp, follow the temperature conditions given in the chapter on TECHNICAL FEATURES. Do not leave the lamp in a hot or cold environment for a long time.

Technical features

<b>LAMP</b>		<b>MAIN LIGHT AUTONOMY:</b>	
Total length (mm):	174	High Brightness mode:	2h
Dimensions of "main light source body" (mm)	61 x 11	Minimum Brightness mode:	5h
(W x D):		<b>TOP LIGHT AUTONOMY:</b>	
Weight (g):	76	3h	
<b>CHARACTERISTICS OF THE MAIN LIGHT SOURCE:</b>		<b>CHARGING TIME OF THE BATTERY:</b>	
Type:	COB LED	Charging time:	2h 30min
Power:	2 W	By:	USB
Brightness (min – max):	60 lm – 200 lm	<b>PROTECTION DEGREE:</b>	
Variable intensity on 3 levels	by pressing the power button	IP20	
<b>TOP LIGHT FEATURES:</b>		<b>OPERATION AND STORAGE TEMPERATURE:</b>	
Type:	SMD LED	Storage:	da -20°C a +50°C (1 year)
Power:	1 W	In charge:	da -10°C a +40°C
Brightness:	100 lm	In operation:	da -10°C a +40°C
<b>BATTERY:</b>			
Type:	Li-Po		
Features:	3.7 V DC, 700 mAh		

Safety instructions

Attention:

failure to observe these safety instructions could cause serious damage to people, the environment and the lamp itself.

- This device is not a toy. Keep out of reach of children.
- The packing material (cardboard box, plastic sheets, etc.) must not be used by children for play.
- Do not immerse or subject the device to water jets.

- Do not use the lamp in a potentially explosive atmosphere, such as near combustibles. Flammable gases or powders. Respect and comply with the limitations and provisions of the law.
- Do not throw into fire or expose to fire. Danger of explosion.
- Fall events can irreparably damage the lamp and its accessories and are not covered by warranty. In this case, in order to avoid any risk, do not use the lamp and its accessories, but contact an authorized service center.
- Do not attempt to open the lamp or accessories supplied; there are no replaceable parts. Interventions by unqualified personnel are potentially dangerous and invalidate the warranty.
- Use only the accessories supplied with the lamp. The use of non-original accessories will result in the loss of the warranty and could be a source of danger with risks of fire, explosion, leakage of liquid or other hazards. For availability of original accessories, contact an authorized dealer.
- For use and charging, comply with the temperature conditions given in the chapter on TECHNICAL SPECIFICATIONS.


- Avoid exposure to excessively high temperatures which can shorten the life of electronic circuits, damage batteries and deform or melt plastic parts.
- Avoid exposure to too low temperatures that can reduce battery life or make plastic components fragile.
- Avoid handling or disconnecting the charging device by pulling it by the cable.

Use instructions

This lamp has two light sources: the main light source (COB LED) and the spot light on the top.

The main light source has two different levels of brightness (low 60lm, 200lm high) that can be selected simply by pressing lightly on the power button on the back.

The top light is activated with the first press on the power button on the back.



The lamp is equipped with a magnetic base on which the lamp can rotate 360 ° and can be tilted.



The lamp battery is recharged using the supplied USB cable.

Disposal information



This product falls within the scope of the Directive 2012/19/EU (RAEE). The symbol of a crossed-out bin on the product and/or on the packaging, means that this product is not to be disposed off with your household waste, it should be handed over to an authorized collection site for disposal and recycling. This operation has to be carried out by the consumer. The correct disposal of the product will contribute to avoid the possible negative effects on the environment and encourages the usage of renewable resources.

EU declaration of conformity

This product is in compliance with the following European Directives:

<b>2014/30/EU (EMC)</b>	EN 55015:2013/A1:2015
	EN 61547:2009
	EN 55022:2010
	EN 61000-3-2:2014 EN 61000-3-3:2013 EN 55024:2010
<b>2011/65/EU (RoHS)</b>	EN 62321-1:2013
	EN 62321-2:2014
	EN 62321-3:2014
	EN 62321-4:2014
	EN 62321-5:2014
	EN 62321-6:2015 EN 62321:2009

Warranty

This lamp is guaranteed 24 months from the date of the document that proves the purchase; in the case of purchase for a legal purpose or professional activity, the warranty is valid for 12 months from the date of purchase receipt. The warranty is not extended for periods of downtime caused by repairs. In order to have right to warranty the buyer should always present the purchase receipt. Warranty means the repair or replacement free of charge, including work, components found defective in manufacture or materials. The warranty does not apply in all cases where the damage is caused by carelessness, use or maintenance not in accordance with the instructions of this manual; particularly in case of product tampering or negligence of the customer. The warranty does not apply to failures caused by inductive/electrostatic dischargers caused by lightning or other external events to the product. The warranty does not extend to parts subject to wear due to use, connecting cables and connectors that are free from defects in manufacture are excluded from the warranty.