

## Safety instructions and instruction manual

FG 222/B

RECHARGEABLE LED LAMP WITH WIRELESS SPEAKER



Equipped with AC battery charger.



### Warnings



Before to use the tool, please read carefully the instruction contained in this manual. Improper or unsafe use of this tool can result in death or serious bodily injury. This manual of instructions constitutes an integral part of product and it has to be edited by the end user for every possible future consultation. It contains important informations about the safety use of the product.



**Use destination.** This tool and its accessories, must only be used for the purpose for which they have been conceived. A different use from that one suitable could cause damages to people, animals or things and it's considered improper and unreasonable action. The producer can't be considered responsible for possible damages caused by improper, wrong and unreasonable uses, as, for example, the un-observance of the safety instruction, the use of no original accessories and operation not authorized on the product.

### Precautions for use

The informations in this section will help you to comply with the warranty requirements and keep the lamp in good working order.

- Turn off the lamp when it is not in use.
- Never leave the lamp with the battery completely empty.
- Fully recharge the battery if the lamp is not to be used for a long time.
- Before cleaning the lamp, always disconnect the charging cable.
- Clean preferably with a dry or slightly damp cloth. Do not use solvents, alcohol, corrosive chemicals or aggressive detergents.

• To use, charge and store the lamp, follow the temperature conditions given in the chapter on TECHNICAL FEATURES. Do not leave the lamp in a hot or cold environment for a long time.

### Technical features

LAMP	
SIZE (mm):	210 X 210 X 100
NET WEIGHT (g):	1560
FEATURES	
LED TYPE:	COB – 45W 6500K
PROTECTION CLASS:	III
DEGREE OF PROTECTION:	IP65
LUMINOUS FLUX:	4000 lm (High) 2000 lm (Medium) 1000 lm (Low) 400 lm (ECO)
WIRELESS SPEAKER:	SI (2)
FREQUENCY RANGE:	2402 – 2480 MHz
POWER BANK FUNCTION:	Output max 5V, 1A
RUN TIME	
at 4000 lm:	3.5 h
at 2000 lm:	6 h
at 1000 lm:	10 h
at 400 lm:	18 h
POWER BANK mode:	9 h
MUSIC MODE:	5 – 8 h
BATTERY	
TYPE:	Li-Ion
FEATURES:	11.1V 5200mAh 5V.72Wh
RECHARGE	
TIME:	3.5 h
WITH:	supplied battery charger
CHARGER (SUPPLIED):	AC Input: 100-240V DC Output: 15V 1.5A
TEMPERATURE	
IN CHARGE:	from -10 °C to +40 °C
WORKING:	from -10 °C to +40 °C
STORAGE:	from -10 °C to +40 °C



**Attention:** failure to observe these safety instructions could cause serious damage to people, the environment and the lamp itself.

- This device is not a toy. Keep out of reach of children.
- The packing material (cardboard box, plastic sheets, etc.) must not be used by children for play.
- Do not look or point the light directly in your eyes.
- Do not use the lamp in a potentially explosive atmosphere, such as near combustibles. Flammable gas or dust. Respect and abide by the limitations and provisions of the law.
- Do not throw into fire or expose to flames. Danger of explosion.
- Falling events can irreparably damage the lamp and its accessories and are not covered by warranty. In this case, in order to avoid any risk, do not use the lamp and its accessories, but contact an authorized service center.
- Do not try to open the lamp or the accessories supplied; there are no replaceable parts. Interventions by unqualified personnel are potentially dangerous and invalidate the guarantee.
- Use only the accessories supplied with the lamp. The use of non-original accessories will invalidate the warranty and could be a source of danger with the risk of fire, explosion, liquid leakage or other dangers. For the availability of original accessories, contact an authorized dealer.

• For use and charging, follow the temperature conditions listed in the chapter of TECHNICAL FEATURES

• Avoid exposure to temperatures that are too high, which can reduce the life of electronic circuits, damage batteries and deform or melt plastic parts.

• Also avoid exposure to too low temperatures which can reduce battery life or make plastic components fragile.

• Avoid handling or disconnecting the charging device by pulling it by the cable.

### Instructions for use

The lamp turns on by turning the appropriate ON/OFF knob on the back of the lamp clockwise: it starts in ECO mode and then reaches High intensity mode.

This lamp is equipped with two wireless speakers: it is possible to connect the lamp to a device equipped with Bluetooth by pressing the "wireless speakers" button located on the back of the lamp next to the ON/OFF wheel - the blue LED above the same button will flash and it will be emitted an acoustic signal (the lamp will be detected by the device as "Audio Floodlight"); by starting the music on the device you will be able to listen to the music with the lamp. The volume must be adjusted on the device (PC, smartphone, etc.). To switch off the loudspeakers, press and hold the "wireless loudspeaker" button: an acoustic signal will sound and the blue LED will turn off.

The lamp is also equipped with a Power Bank function (max 5V, 1A): insert the appropriate USB cable into the socket marked OUTPUT.

The lamp is equipped with 5 green LEDs which indicate the state of charge when the lamp is switched on.

To recharge the lamp, insert the connector of the supplied wall charger into the socket indicated by the word INPUT.



The body of the lamp can rotate up to 140° by unscrewing the two small green knobs on the sides. It can also be hung by pulling out the swivel hook incorporated in its base.

### Disposal informations



This equipment falls within the equipment field of Directive 2012/19/ EU. The crossed-out bin symbol on the product and / or its packaging means that at the end of its life the product must be treated separately from household waste and therefore must be sent to the appropriate disposal and recycling centers. This operation is the responsibility of the user. Disposing of the product at the appropriate dedicated facilities helps to avoid possible negative effects on the environment and favors the reuse of renewable resources.

### EU declaration of conformity

FASANGAS SRL  
Viale Grecia 3, 73100 Zona Industriale Lecce (LE) ITALY

#### DECLARES THAT

that the product AUDIO FLOODLIGHT (2402-2480MHz) Input: DC 15V, 1500mA; USB Output: DC 5V, 1000mA; Protection class: III)

FG 222/B  
(model)

#### IS IN ACCORDANCE

WITH THE FOLLOWING EUROPEAN DIRECTIVES

2014/53/EU RED Directive  
2011/65/EU RoHS Directive

Harmonized standards used for compliance with the Essential Safety Requirements of the Directives

2014/53/EU	EN 55022:2015
	EN IEC 55015:2019
	EN 55025:2017
	EN 61547:2009
2011/65/EU	EN 301488-1 V.2.2.3:2019
	EN 301488-1 V.2.2.2:2019
	EN 301488-1 V.2.2.3:2019
	EN 62479:2015
2011/65/EU	IEC 62321-3-2:2013
	IEC 62321-4-2:2013-AMD1:2017
	IEC 62321-5:2013
	IEC 62321-1:2015
	IEC 62321-2:2015
	IEC 60177-1:2017
	IEC 62321-4:2017
	IEC 62321-8:2017

Date: 30 MAY 2023

Sign of the Legal Representative

### Warranty

This lamp is guaranteed for 24 months from the date purchase. By warranty we mean the repair or replacement free of charge, including labor, of components recognized as defective in manufacturing and material. The guarantee does not apply in all those cases in which the damage is caused by neglect, use and maintenance that do not comply with the instructions in this manual; in particular in case of product tampering or user negligence. The warranty does not apply to failures caused by inductive / electrostatic discharges or discharges caused by lightning or other events external to the product. Parts subject to wear due to use, connection cables and connectors that do not have manufacturing defects are excluded from the guarantee.

Cod.: FG 222/B - Rev.07.2023